



strap fitting




1

To attach the strap, pull back lever



2

Hold back lever, place pins into designated holes



3

Click into place and release lever

IOTA

www.iota.london